

PCR-cDNA Barcoding (SQK-PCB109)

Version: PCB_9092_v109_revB_10Oct2019
 Last update: 09/12/2020



Flow Cell Number:

DNA Samples:

Before start checklist		
Materials	Consumables	Equipment
<input type="checkbox"/> 1 ng PolyA+ RNA (or ~50 ng total RNA)	<input type="checkbox"/> Agencourt AMPure XP beads	<input type="checkbox"/> Hula mixer (gentle rotator mixer)
<input type="checkbox"/> PCR-cDNA Barcoding kit (SQK-PCB109)	<input type="checkbox"/> 1.5 ml Eppendorf DNA LoBind tubes	<input type="checkbox"/> Magnetic separator, suitable for 1.5 ml Eppendorf tubes
<input type="checkbox"/> Flow Cell Priming Kit (EXP-FLP002)	<input type="checkbox"/> 0.2 ml thin-walled PCR tubes	<input type="checkbox"/> Microfuge
	<input type="checkbox"/> Nuclease-free water (e.g. ThermoFisher, cat # AM9937)	<input type="checkbox"/> Vortex mixer
	<input type="checkbox"/> Freshly prepared 70% ethanol in nuclease-free water	<input type="checkbox"/> Thermal cycler
	<input type="checkbox"/> 10 mM dNTP solution (e.g. NEB N0447)	<input type="checkbox"/> Ice bucket with ice
	<input type="checkbox"/> LongAmp Taq 2X Master Mix (e.g. NEB M0287)	<input type="checkbox"/> Timer
	<input type="checkbox"/> Maxima H Minus Reverse Transcriptase (200 U/μl) with 5x RT Buffer (ThermoFisher, cat # EP0751)	<input type="checkbox"/> Pre-chilled freezer block at -20° C for 200 μl tubes (e.g. Eppendorf 022510509)
	<input type="checkbox"/> RNaseOUT™, 40 U/μl (Life Technologies, 10777019)	<input type="checkbox"/> Qubit fluorometer (or equivalent for QC check)
	<input type="checkbox"/> Exonuclease I (NEB, M0293)	<input type="checkbox"/> Pipettes and pipette tips P2, P10, P20, P100, P200, P1000

INSTRUCTIONS	NOTES/OBSERVATIONS
<p>Reverse transcription and strand-switching</p> <p>Prepare the following reaction in a 0.2 ml PCR tube:</p> <ul style="list-style-type: none"> <input type="checkbox"/> x μl 1 ng PolyA+ RNA (or ~50 ng total RNA) <input type="checkbox"/> 1 μl VN Primers (VNP), at 2 μM <input type="checkbox"/> 1 μl 10 mM dNTPs <input type="checkbox"/> 9-x μl RNase-free water <p><input type="checkbox"/> Mix gently by flicking the tube, and spin down.</p> <p><input type="checkbox"/> Incubate at 65° C for 5 minutes and then snap cool on a pre-chilled freezer block.</p> <p>In a separate tube, mix together the following:</p> <ul style="list-style-type: none"> <input type="checkbox"/> 4 μl 5x RT Buffer <input type="checkbox"/> 1 μl RNaseOUT <input type="checkbox"/> 1 μl Nuclease-free water <input type="checkbox"/> 2 μl Strand-Switching Primer (SSP, at 10 μM) <p><input type="checkbox"/> Mix gently by flicking the tube, and spin down.</p>	

PCR-cDNA Barcoding (SQK-PCB109)

Version: PCB_9092_v109_revB_10Oct2019
 Last update: 09/12/2020



Flow Cell Number:

DNA Samples:

INSTRUCTIONS	NOTES/OBSERVATIONS
<p><input type="checkbox"/> Add the strand-switching buffer to the snap-cooled, annealed mRNA, mix by flicking the tube and spin down.</p> <p><input type="checkbox"/> Incubate at 42° C for 2 minutes.</p> <p><input type="checkbox"/> Add 1 µl of Maxima H Minus Reverse Transcriptase. The total volume is now 20 µl.</p> <p><input type="checkbox"/> Mix gently by flicking the tube, and spin down.</p> <p>Incubate using the following protocol:</p> <ul style="list-style-type: none"> <input type="checkbox"/> Reverse transcription and strand-switching 90 mins @ 42° C (1 cycle) <input type="checkbox"/> Heat inactivation 5 mins @ 85° C (1 cycle) <input type="checkbox"/> Hold @ 4° C 	
<p>Selecting for full-length transcripts by PCR and barcoding samples</p>	
<p>The PCR steps outlined below adds barcodes to each reverse transcribed RNA (cDNA) sample. The Barcode Primers provided in the PCR-cDNA Barcoding kit (SQK-PCB109) are used to barcode/multiplex up to 12 individual samples on a single flow cell.</p>	
<p>IMPORTANT</p> <p><input type="checkbox"/> Each PCR reaction uses 5 µl of reverse transcribed RNA sample (out of a total of 20 µl). Therefore, sufficient material is available to perform up to four PCR reactions per sample. Do NOT, however, use all 20 µl of reverse transcribed RNA (cDNA) in a single PCR reaction.</p>	
<p>IMPORTANT</p> <p><input type="checkbox"/> This kit enables multiplexing of up to 12 samples. The default method allows you to perform one 50 µl PCR reaction per sample. If multiplexing two or three samples, however, two separate PCR reactions per sample should be performed; if running just one sample, four separate PCR reactions should be performed. These recommendations aim to ensure that enough PCR product is generated for optimal flow cell performance.</p>	
<p>It is recommended that any remaining reverse transcription reaction is retained to allow for further PCR reactions if greater yield is required.</p> <p>For each sample (up to 12), prepare the following reaction at RT:</p> <ul style="list-style-type: none"> <input type="checkbox"/> 5 µl Reverse-transcribed RNA sample <input type="checkbox"/> 1.5 µl Barcode Primers (BP01-BP12) <input type="checkbox"/> 18.5 µl Nuclease-free water <input type="checkbox"/> 25 µl 2x LongAmp Taq Master Mix <p>Amplify using the following cycling conditions:</p> <ul style="list-style-type: none"> <input type="checkbox"/> Initial denaturation 30 secs @ 95° C (1 cycle) <input type="checkbox"/> Denaturation 15 secs @ 95° C (11-18* cycles) <input type="checkbox"/> Annealing 15 secs @ 62° C (11-18* cycles) <input type="checkbox"/> Extension 50 secs per kb @ 65° C (11-18* cycles) <input type="checkbox"/> Final extension 6 mins @ 65° C (1 cycle) <input type="checkbox"/> Hold @ 4° C <p><input type="checkbox"/> Add 1 µl of NEB Exonuclease 1 directly to each PCR tube. Mix by pipetting.</p>	

PCR-cDNA Barcoding (SQK-PCB109)

Version: PCB_9092_v109_revB_10Oct2019
 Last update: 09/12/2020



Flow Cell Number:

DNA Samples:

INSTRUCTIONS	NOTES/OBSERVATIONS
<p><input type="checkbox"/> Incubate the reaction at 37° C for 15 min, followed by 80° C for 15 minutes.</p> <p><input type="checkbox"/> Pool any PCR reactions containing the same barcoded sample in a clean 1.5 ml Eppendorf DNA LoBind tube.</p> <p><input type="checkbox"/> Resuspend the AMPure XP beads by vortexing.</p> <p><input type="checkbox"/> Add 0.8X equivalents of resuspended AMPure XP beads to the reaction and mix by pipetting.</p> <p><input type="checkbox"/> Incubate on a Hula mixer (rotator mixer) for 5 minutes at RT.</p> <p><input type="checkbox"/> Prepare 500 µl of fresh 70% ethanol in Nuclease-free water.</p> <p><input type="checkbox"/> Spin down the sample and pellet on a magnet. Keep the tube on the magnet, and pipette off the supernatant.</p> <p><input type="checkbox"/> Keep the tube on the magnet and wash the beads with 200 µl of freshly prepared 70% ethanol without disturbing the pellet. Remove the ethanol using a pipette and discard.</p> <p><input type="checkbox"/> Repeat the previous step.</p> <p><input type="checkbox"/> Spin down and place the tube back on the magnet. Pipette off any residual 70% ethanol. Briefly allow to dry.</p> <p><input type="checkbox"/> Remove the tube from the magnetic rack and resuspend pellet in 12 µl of Elution Buffer (EB).</p> <p><input type="checkbox"/> Incubate on a Hula mixer (rotator mixer) for 10 minutes at RT.</p> <p><input type="checkbox"/> Pellet beads on magnet until the eluate is clear and colourless.</p> <p>Remove and retain 12 µl of eluate which contains the DNA library in a clean 1.5 ml Eppendorf DNA LoBind tube.</p> <p><input type="checkbox"/> Dispose of the pelleted beads</p> <p><input type="checkbox"/> Analyse 1 µl of the amplified DNA for size, quantity and quality.</p>	
<p>IMPORTANT</p> <p><input type="checkbox"/> Sometimes a high-molecular weight product is visible in the wells of the gel when the PCR products are run, instead of the expected smear. These libraries are typically associated with poor sequencing performance. We have found that repeating the PCR with fewer cycles can remedy this.</p>	
<p>In a 1.5 ml Eppendorf DNA LoBind tube, pool together a total of 100 fmol of the amplified cDNA barcoded samples to a final volume of 11 µl in Elution Buffer (EB).</p> <p><input type="checkbox"/> Please check the Mass to Molarity table in the protocol</p>	
<p>Adapter addition</p>	
<p><input type="checkbox"/> Add 1 µl of Rapid Adapter (RAP) to the amplified cDNA library.</p> <p><input type="checkbox"/> Mix by pipetting and spin down.</p> <p><input type="checkbox"/> Incubate the reaction for 5 minutes at RT.</p> <p><input type="checkbox"/> Spin down briefly.</p>	

PCR-cDNA Barcoding (SQK-PCB109)

Version: PCB_9092_v109_revB_10Oct2019
 Last update: 09/12/2020



Flow Cell Number:

DNA Samples:

INSTRUCTIONS	NOTES/OBSERVATIONS
<p>The prepared library is used for loading onto the flow cell. Store the library on ice until ready to load.</p>	
<p>Priming and loading the SpotON flow cell</p>	
<p>IMPORTANT</p> <p><input type="checkbox"/> Please note that the Sequencing Tether (SQT) tube will NOT be used in this protocol. It is provided in the kit for potential future product compatibility.</p>	
<p><input type="checkbox"/> Thaw the Sequencing Buffer (SQB), Loading Beads (LB), Flush Tether (FLT) and one tube of Flush Buffer (FB) at RT.</p> <p><input type="checkbox"/> Mix the Sequencing Buffer (SQB), Flush Tether (FLT) and Flush Buffer (FB) tubes by vortexing and spin down at RT.</p> <p><input type="checkbox"/> Open the MinION Mk1B lid and slide the flow cell under the clip.</p> <p><input type="checkbox"/> Slide the priming port cover clockwise to open the priming port.</p>	
<p>IMPORTANT</p> <p><input type="checkbox"/> Take care when drawing back buffer from the flow cell. Do not remove more than 20-30 μl, and make sure that the array of pores are covered by buffer at all times. Introducing air bubbles into the array can irreversibly damage pores.</p>	
<p>After opening the priming port, check for a small air bubble under the cover. Draw back a small volume to remove any bubbles (a few μl):</p> <ul style="list-style-type: none"> <input type="checkbox"/> Set a P1000 pipette to 200 μl <input type="checkbox"/> Insert the tip into the priming port <input type="checkbox"/> Turn the wheel until the dial shows 220-230 μl, or until you can see a small volume of buffer entering the pipette tip <p><input type="checkbox"/> Prepare the flow cell priming mix: add 30 μl of thawed and mixed Flush Tether (FLT) directly to the tube of thawed and mixed Flush Buffer (FB), and mix by vortexing.</p> <p><input type="checkbox"/> Load 800 μl of the priming mix into the flow cell via the priming port, avoiding the introduction of air bubbles. Wait for 5 minutes. During this time, prepare the library for loading by following the steps below.</p> <p><input type="checkbox"/> Thoroughly mix the contents of the Loading Beads (LB) by pipetting.</p>	
<p>IMPORTANT</p> <p><input type="checkbox"/> The Loading Beads (LB) tube contains a suspension of beads. These beads settle very quickly. It is vital that they are mixed immediately before use.</p>	
<p>In a new tube, prepare the library for loading as follows:</p> <ul style="list-style-type: none"> <input type="checkbox"/> 37.5 μl Sequencing Buffer (SQB) <input type="checkbox"/> 25.5 μl Loading Beads (LB), mixed immediately before use <input type="checkbox"/> 12 μl DNA library <p>Complete the flow cell priming:</p> <ul style="list-style-type: none"> <input type="checkbox"/> Gently lift the SpotON sample port cover to make the SpotON sample port accessible. <input type="checkbox"/> Load 200 μl of the priming mix into the flow cell via the priming port (not the SpotON sample port), avoiding the introduction of air bubbles. 	

PCR-cDNA Barcoding (SQK-PCB109)

Version: PCB_9092_v109_revB_10Oct2019
Last update: 09/12/2020



Flow Cell Number:

DNA Samples:

INSTRUCTIONS	NOTES/OBSERVATIONS
<ul style="list-style-type: none"><input type="checkbox"/> Mix the prepared library gently by pipetting up and down just prior to loading.<input type="checkbox"/> Add 75 µl of sample to the flow cell via the SpotON sample port in a dropwise fashion. Ensure each drop flows into the port before adding the next.<input type="checkbox"/> Gently replace the SpotON sample port cover, making sure the bung enters the SpotON port, close the priming port and replace the MinION Mk1B lid.	
Ending the experiment	
<ul style="list-style-type: none"><input type="checkbox"/> After your sequencing experiment is complete, if you would like to reuse the flow cell, please follow the Wash Kit instructions and store the washed flow cell at 2-8°C, OR<input type="checkbox"/> Follow the returns procedure by washing out the flow cell ready to send back to Oxford Nanopore.	
IMPORTANT <ul style="list-style-type: none"><input type="checkbox"/> If you encounter issues or have questions about your sequencing experiment, please refer to the Troubleshooting Guide that can be found in the online version of this protocol.	